REW(I)　　　　　　　　　　　　　　　　　　　　　　　　　　　　　　　　**REW(I)**

NAME
　　rew　—　rewind tape

SYNOPSIS
　　rew [[**m**]digit]

DESCRIPTION
　　Rew rewinds DECtape or magtape drives. The digit is the logical tape number, and should
　　range from 0 to 7. if the digit is preceded by **m**, *rew* applies to magtape rather than DECtape.
　　A missing digit indicates drive 0.

FILES
　　/dev/tap?
　　/dev/mt?

BUGS
　　Magnetic tape units 4-7 map into physical drives 0-3.